

WK17-6 & WK17-4 BACKFILL REMOVAL BLADES RECOMMENDED OPERATION

1. Ensure blade cutting tips and edges are sharp at all times.
2. Apply ample cutting lubrication to the cutting area.
3. Keep the BTB power tool and blade parallel to the glass surface (refer diagrams below).
4. Do not force or twist the blade. Force or incorrect use may cause blade breakage.
5. Maximum power is not always required.
6. If forward motion is slowed due to hard urethane, pull blade slightly backward and forward then guide the blade forward again.
7. For additional control, use these blades in conjunction with the WK26 controller arm.

